

1) Slide the ferrule onto the cable and strip the cable to the dimensions as shown, taking care not to nick the centre conductor or braid.



2) Crimp the pin onto the centre core and slide the pin into the body, ensuring that the cable braid is on the outside of the connector mandril and that the pin is fully located.



3) Slide the ferrule forward and crimp.



Recommended Crimp Tool(s): PCC0308 Crimp Hex. Sizes: 3.25mm Hex., 0.72mm Square

This document is the property of Gigatronix Limited and may not be copied or reproduced without written authorisation from Gigatronix limited. Revision Control No. 110624.1. website: www.gigatronix.co.uk email:sales@gigatronix.co.uk